



# **BREAK-THROUGH!®**

Architectural Coatings

#### **GENERAL DESCRIPTION**

A versatile, ultra-durable water-borne acrylic, Break-Through!, is formulated to bond to some of the most difficult substrates including fiberglass, laminate, and many plastics. The interior/exterior satin finish offers very fast dry and outstanding early block resistance for increased productivity with less down time. Break-Through! provides hardness similar to or better than standard alkyds with a low VOC formula, but maintains flexibility to endure extreme bends and deformation without cracking and peeling. Break-Through! is ideal for doors, windows, cabinets, shelving, hand rails, fixtures, trim, wood and concrete floors.

## RECOMMENDED SUBSTRATES

Aluminum Galvanized Steel Concrete Gypsum Wallboard-Drywall

Concrete/Masonry Block Interior Wood Ferrous Metal Laminate

**Fiberglass** Vinyl and Architectural Plastics

Plaster

## CONFORMANCE STANDARDS

VOC compliant - lower than current Canadian AIM regulations Can help earn LEED 2009 credits

## APPLICATION INFORMATION

Stir thoroughly before using and occasionally when in use. Prime all necessary surfaces with an appropriate PPG primer prior to application of the product. When using more than one container of the same colour, intermix to ensure colour uniformity. Do not mix with solvent-type paints or with paint solvents. USE WITH ADEQUATE VENTILATION. KEEP OUT OF REACH OF CHILDREN. Read all label and Material Safety Data Sheet (MSDS) information prior to use. MSDS are available through our website or by calling 1-800-441-9695.

**Application Equipment:** Apply with a high quality synthetic brush, roller, paint pad, or by spray equipment. necessary, apply a second coat.

Airless Spray: Pressure 2000 psi, tip 0.009" - 0.013". Best results are achieved using a fine finish tip.

Spray equipment must be handled with due care and in accordance with manufacturer's recommendation. Highpressure injection of coatings into the skin by airless equipment may cause serious injury.

Brush: High quality polyester/nylon brush Roller: 3/16" - 3/8" nap roller cover.

Thinning: No thinning required for airless or air-assisted airless application. Reduce 5-10% with clean water for conventional spray, HVLP and brush applications.

**DISPOSAL:** Contact your local environmental regulatory agency for guidance on disposal of unused product. Do not pour down a drain or storm sewer.

Break-Through! 50 Interior/Exterior Satin Water-Borne Acrylic

# APPLICATION INFORMATION (continued)

Permissible temperatures during application:

10 to 32°C Material: 10 to 32°C Ambient: Substrate: 10 to 32°C

## TINTING AND BASE INFORMATION

Refer to the appropriate colour formula book, automatic tinting equipment, and/or computer colour matching system for colour formulas and tinting instructions. The bases can be tinted with 96 line or 896

colourants.

V56-410C White and Pastel Base

V56-420C Midtone\* Deeptone\* V56-430C V56-440C Ultra Deep\* V56-35C **Bronze** 

V56-90C Wrought Iron Black

\*Must be tinted before use.

Some colours, drastic colour changes, or porous substrates may require more than one coat to achieve a uniform finish. Safety colours and high chroma colours should be tinted with 896 colourants for optimum performance.

#### PRODUCT DATA

PRODUCT TYPE: Water-borne Acrylic

Satin: 20 to 25 (60° Gloss Meter) SHEEN:

**VOLUME SOLIDS\*:** 40% +/- 2% 55% +/- 2% **WEIGHT SOLIDS\*:** VOC\*: 50 g/L WEIGHT/GALLON\*: 5.0 kg +/- 91 g \*Product data calculated on product V56-410C.

COVERAGE: Approximately 37 sq. m/3.78L depending on surface

texture and porosity.

Wet Film Thickness: 4.0 mils Wet Microns: 102 microns Dry Film Thickness: 1.6 mils Dry Microns: 41 microns

Coverage figures do not include loss due to surface irregularities and

porosity or material loss due to application method or mixing. DRYING TIME: Dry time @ 25°C; 50% relative humidity.

To Touch: 15 to 20 minutes

To Handle: 1 hour To Recoat: After 2 hours For Foot Traffic: 12 hours For Forklift Traffic: 36 hours To Full Cure: 7 days

Drying times listed may vary depending on temperature, humidity, colour and air movement.

**CLEANUP:** Clean tools and spray equipment with warm, soapy

water immediately after use.

Over 93°C FLASH POINT:

#### FEATURES / BENEFITS

**Features Benefits** 

Low VOC and low odor Meets the most stringent regulatory standards

Provides tack free film ideal for doors, windows, cabinets, shelving

Outstanding block resistance Very good adhesion Bonds to a wide variety of difficult substrates

Very good hardness Durability and hardness similar or better than conventional alkyds

Quick dry Dry to touch in 15-20 minutes; results in less down time Excellent flow & leveling Provides enamel smooth finish with less brush marks

Flexible Withstands bends with no cracking or peeling

Resistant to household chemicals Ideal for use in areas requiring frequent cleaning with mild household cleaners or light duty

industrial cleaners

**Architectural Coatings** 

Break-Through! 50 Interior/Exterior Satin Water-Borne Acrylic

## **GENERAL SURFACE PREPARATION**

Surfaces to be coated must be dry, clean, sound, and free from all contamination including loose and peeling paint, dirt, grease, oil, wax, concrete curing agents and bond breakers, chalk, efflorescence, mildew, rust, product fines, and dust. Remove loose paint, chalk, and efflorescence by wire brushing, scraping, sanding, and/or pressure washing. Putty all nail holes and caulk all cracks and open seams. Sand all glossy, rough, and patched surfaces. Feather back all rough edges to sound surface by sanding. Prime all bare and porous substrates with an appropriate primer. On exterior surfaces, remove mildew by using PPG MILDEW CHECK® Multi-Purpose Wash, 18-1; or 1 part chlorine bleach to 3 parts water. Before use, be sure to read and follow the instructions and warnings on the label. WARNING! If you scrape, sand, or remove old paint, you may release lead dust or fumes. LEAD IS TOXIC. EXPOSURE TO LEAD DUST OR FUMES CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a properly fitted NIOSH-approved respirator and prevent skin contact to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the USEPA National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead. In Canada contact a regional Health Canada office. Follow these instructions to control exposure to other hazardous substances that may be released during surface preparation.

**Aluminum:** A primer is required for proper adhesion. Any coating applied directly to aluminum should be spot applied, allowed to cure overnight, and then evaluated for adhesion. If adhesion is good, the application may proceed.

**Ferrous Metal:** The surface must be cleaned thoroughly to remove any dust, rust, oil, and surface contaminants, and then primed. No primer is required for interior applications.

**Galvanized Steel:** A primer is required for proper adhesion. Caution must be used when selecting coatings for use on all galvanized metal surfaces. These substrates may have a factory-applied stabilizer, which is used to prevent white rusting during storage and shipping. Such stabilizers must be removed by either brush blasting, sanding or chemical treatment prior to priming.

**Interior Wood:** Unpainted wood or wood in poor condition should be sanded smooth, wiped clean, then primed. Any knots or resinous areas must be primed before painting. For non-bleeding or previously painted wood, no primer is required.

**Concrete:** New concrete should cure for at least 30 days and preferably 90 days prior to priming and painting. The pH of the substrate must be less than 10 before painting, priming If pH is greater than 10, prime with an alkali resistant primer.

**Concrete/Masonry Block**: Mortar should cure for at least 30 days and preferably 90 days prior to priming. Fill block with appropriate block filler. Surfaces previously coated with water thinned cement-based paint must be prepared with extra care. If the material appears to be adhering tightly, a masonry sealer may be applied to seal the surface.

**Gypsum Wallboard/Drywall:** Nails or screws should be countersunk, and they along with any indentations should be mudded flush with the surface, sanded smooth and cleaned to remove any dust, then prime prior to painting the substrate.

Plaster: Plaster or other alkaline surfaces should be allowed to cure for at least 30 days prior to priming with an alkali resistant primer.

**Fiberglass:** No primer needed; sanding or scuffing the surface is recommended. Primer and topcoat should be spot applied as directed, allowed to cure overnight, then evaluated for adhesion. If adhesion is good, the application may proceed.

**Laminate:** No primer needed; sanding or scuffing the surface is recommended. Topcoat should be spot applied as directed, allowed to cure overnight, then evaluated for adhesion. If adhesion is good, the application may proceed.

**Vinyl & Architectural Plastics:** Vinyl and similar architectural plastics may present potential adhesion problems. A primer may be required to promote proper adhesion. Consult the manufacturer's guidelines prior to painting. Primer and Topcoat should be spot applied, allowed to cure overnight, then evaluated for adhesion. If adhesion is good, the application may proceed. Do not paint vinyl or plastic with a colour darker than the original to prevent potential warping due to heat absorption.

#### RECOMMENDED PRIMERS

Aluminum 6-204C, 17-921C, 90-712, 90-912 Concrete 4-603C, Self-priming Concrete/Masonry Block 4-100C, 6-7C, 6-15C

Ferrous Metal 6-208C, 90-712, 90-912

Fiberglass Self-priming

Galvanized Steel 6-209C, 17-921C, 90-712, 90-912

Gypsum Wallboard/Drywall 5-2C, 6-2C, 6-4C, 9-900C Interior Wood 6-2C, 9-900C, 17-921C

Laminate Self-priming
Plaster 4-603C, 17-921C
Vinyl & Architectural Plastics Self-priming

#### PACKAGING

3.78 L

The PPG logo and *Break-Through!* are registered trademarks and *Ecological Solutions* from PPG is a trademark of PPG Industries Ohio, Inc. MILDEW CHECK is a registered trademark of PPG Architectural Finishes, Inc.



PPG Industries, Inc.
Architectural Coatings
One PPG Place
Pittsburgh, PA 15272
www.ppgpittsburghpaints.com

PPG Canada, Inc. Architectural Coatings 4 Kenview Blvd Brampton, ON L6T 5E4 Architect/Specifier 1-888-PPG-IDEA

Technical Services 1-800-441-9695 1-888-807-5123 fax

## LIMITATIONS OF USE

Apply only when air and surface temperatures are above 10°C or above and when the air and surface temperatures will remain above 10°C for the next 24 hours. Avoid exterior application late in the day when dew and condensation are likely to form or when rain is anticipated. Not recommended for exterior horizontal surfaces unless these surfaces can be protected from dew and rain for 7 days. Wait at least 7 days after painting before cleaning the surface with a non-abrasive, mild cleanser. Not recommended for polypropylene or polyethylene plastics, roofs, garage floors or concrete floors subject to hot tires, continuous water immersion environments, such as bathtubs, sinks, shower basins and pools. Do not use on large wood structures or the bodies of homes. Not recommended for very flexible substrates subject to abuse; such as canvas, nylon rope or rubber. Not recommended to be blended with the V76 series. PROTECT FROM FREEZING.

PPG Architectural Finishes, Inc. believes the technical data presented is currently accurate: however, no guarantee of accuracy, comprehensiveness, or performance is given or implied. Improvements in coatings technology may cause future technical data to vary from what is in this bulletin. For complete, up-to-date technical information, visit our web site or call 1-800-441-9695.