SAFETY DATA SHEET



Date of issue/Date of revision18 September 2023Version 18

Section 1. Identification	
Product name	: SILVER GRAY LEAD-FREE
Product code	: 498
Other means of identification	: Not available.
Product type	: Liquid.
Relevant identified uses of	f the substance or mixture and uses advised against
Product use	: Industrial applications.
Use of the substance/ mixture	: Coating. Paints. Painting-related materials.
Uses advised against	: Not applicable.
Manufacturer	: PPG Industries, Inc. One PPG Place, Pittsburgh, PA_15272
Emergency telephone number	: (412) 434-4515 (U.S.) (514) 645-1320 (Canada) SETIQ Interior de la República: 800-00-214-00 (México) SETIQ Ciudad de México: (55) 5559-1588 (México)
Technical Phone Number	: (740) 363-9610 (DELAWARE, OH) 8:00 a.m 5:00 p.m. EST

Section 2. Hazards identification

OSHA/HCS status : This material is considered hazardous by the OSHA Hazard Communication Stands (29 CFR 1910.1200).	lard
Classification of the substance or mixture : FLAMMABLE LIQUIDS - Category 2 SKIN IRRITATION - Category 2 SERIOUS EYE DAMAGE - Category 1 CARCINOGENICITY - Category 2 TOXIC TO REPRODUCTION - Category 2 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3 SPECIFIC TARGET ORGAN TOXICITY (REPEATED EXPOSURE) - Category 1 Percentage of the mixture consisting of ingredient(s) of unknown acute toxicity: 3.24 (oral), 7.7% (dermal), 4.4% (inhalation)	

Section 2. Hazards identification

This product contains TiO2 which has been classified as a GHS Carcinogen Category 2 based on its IARC 2B classification. For many products, TiO2 is utilized as a raw material in a liquid coating formulation. In this case, the TiO2 particles are bound in a matrix with no meaningful potential for human exposure to unbound particles of TiO2 when the product is applied with a brush or roller. Sanding the coating surface or mist from spray applications may be harmful depending on the duration and level of exposure and require the use of appropriate personal protective equipment and/or engineering controls (see Section 8).

GHS label elements	
Hazard pictograms	
Signal word	: Danger
Hazard statements	 Highly flammable liquid and vapor. Causes skin irritation. Causes serious eye damage. May cause drowsiness or dizziness. Suspected of causing cancer. Suspected of damaging fertility or the unborn child. Causes damage to organs through prolonged or repeated exposure. (central nervous system (CNS))
Precautionary statements	
Prevention	: Obtain special instructions before use. Do not handle until all safety precautions have been read and understood. Wear protective gloves, protective clothing and eye or face protection. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Use explosion-proof electrical, ventilating or lighting equipment. Use non-sparking tools. Take action to prevent static discharges. Use only outdoors or in a well-ventilated area. Do not breathe vapor. Do not eat, drink or smoke when using this product. Wash thoroughly after handling.
Response	 IF exposed or concerned: Get medical advice or attention. IF INHALED: Remove person to fresh air and keep comfortable for breathing. Call a POISON CENTER or doctor if you feel unwell. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water. IF ON SKIN: Wash with plenty of water. If skin irritation occurs: Get medical advice or attention. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor. Photosensitive agents : In case of accidental eye contact, avoid direct exposure to the sun or other sources of UV light as severe irritation including burns may result. These reactions can be delayed – get medical attention if pain, irritation or blistering occurs after contact. In case of accidental skin contact, avoid direct exposure to the sun or other sources of UV light as severe irritation including burns may result. These reactions can be delayed – get medical attention including burns may result. These reactions can be delayed – get medical attention including burns may result. These reactions can be delayed – get medical attention including burns may result. These reactions can be delayed – get medical attention including burns may result. These reactions can be delayed – get medical attention including burns may result. These reactions can be delayed – get medical attention if pain, irritation, rash or blistering occurs after contact.
Storage	: Store locked up. Store in a well-ventilated place. Keep container tightly closed. Keep cool.
Disposal	: Dispose of contents and container in accordance with all local, regional, national and international regulations.

United States

Page: 3/19

Product name SILVER GRAY LEAD-FREE

Section 2. Hazards identification

Supplemental label elements	: Sanding and grinding dusts may be harmful if inhaled. Repeated exposure to high vapor concentrations may cause irritation of the respiratory system and permanent brain and nervous system damage. Inhalation of vapor/aerosol concentrations above the recommended exposure limits causes headaches, drowsiness and nausea and may lead to unconsciousness or death. Avoid contact with skin and clothing. Wash thoroughly after handling. Emits toxic fumes when heated.
Hazards not otherwise classified	: Prolonged or repeated contact may dry skin and cause irritation.

Section 3. Composition/information on ingredients

Substance/mixture	: Mixture
Product name	: SILVER GRAY LEAD-FREE

Ingredient name	%	CAS number
Solvent naphtha (petroleum), light aliph.	≥10 - ≤20	64742-89-8
ethanol	≥10 - ≤20	64-17-5
titanium dioxide	≥10 - ≤20	13463-67-7
butan-1-ol	≥10 - ≤14	71-36-3
toluene	≥5.0 - ≤10	108-88-3
xylene	≥1.0 - ≤5.0	1330-20-7
Aluminium powder (stabilized)	≥1.0 - ≤5.0	7429-90-5
Stoddard solvent	≥1.0 - ≤5.0	8052-41-3
ethylbenzene	<1.0	100-41-4
4-methylpentan-2-one	<1.0	108-10-1

SUB codes represent substances without registered CAS Numbers.

Any concentration shown as a range is to protect confidentiality or is due to batch variation.

There are no additional ingredients present which, within the current knowledge of the supplier and in the concentrations applicable, are classified as hazardous to health or the environment and hence require reporting in this section.

Occupational exposure limits, if available, are listed in Section 8.

Section 4. First aid measures

If ingestion, irritation, any type of overexposure or symptoms of overexposure occur during or persists after use of this product, contact a POISON CONTROL CENTER, EMERGENCY ROOM OR PHYSICIAN immediately; have Safety Data Sheet information available. Never give anything by mouth to an unconscious or convulsing person.

Description of necessary first aid measures

Eye contact	: Check for and remove any contact lenses. Immediately flush eyes with running water for at least 15 minutes, keeping eyelids open. Seek immediate medical attention. In case of accidental eye contact, avoid direct exposure to the sun or other sources of UV light as severe irritation including burns may result. These reactions can be delayed – get medical attention if pain, irritation or blistering occurs after contact.
Inhalation	: Remove to fresh air. Keep person warm and at rest. If not breathing, if breathing is irregular or if respiratory arrest occurs, provide artificial respiration or oxygen by trained personnel.
Skin contact	: Remove contaminated clothing and shoes. Wash skin thoroughly with soap and water or use recognized skin cleanser. Do NOT use solvents or thinners.

Product name SILVER GRAY LEAD-FREE

Section 4. First	aiu measures
	In case of accidental skin contact, avoid direct exposure to the sun or other sources of UV light as severe irritation including burns may result. These reactions can be delayed – get medical attention if pain, irritation, rash or blistering occurs after contact.
Ingestion	: If swallowed, seek medical advice immediately and show this container or label. Keep person warm and at rest. Do NOT induce vomiting.
	ns/effects, acute and delayed
Potential acute health e	
Eye contact	: Causes serious eye damage.
Inhalation	 Can cause central nervous system (CNS) depression. May cause drowsiness or dizziness.
Skin contact	: Causes skin irritation. Defatting to the skin.
Ingestion Over-exposure signs/sy	: Can cause central nervous system (CNS) depression.
Eye contact	: Adverse symptoms may include the following:
	pain
	watering
	redness
Inhalation	: Adverse symptoms may include the following:
	nausea or vomiting headache
	drowsiness/fatigue
	dizziness/vertigo
	unconsciousness
	reduced fetal weight
	increase in fetal deaths
	skeletal malformations
Skin contact	: Adverse symptoms may include the following:
	pain or irritation
	redness
	dryness
	cracking
	blistering may occur
	reduced fetal weight
	increase in fetal deaths skeletal malformations
Ingestion	: Adverse symptoms may include the following:
ingootion	stomach pains
	reduced fetal weight
	increase in fetal deaths
	skeletal malformations
ndication of immediate r	nedical attention and special treatment needed, if necessary
Notes to physician	: Treat symptomatically. Contact poison treatment specialist immediately if large
	quantities have been ingested or inhaled.
	: No specific treatment.

Product name SILVER GRAY LEAD-FREE

Section 4. First aid measures

Protection of first-aiders
 No action shall be taken involving any personal risk or without suitable training. If it is suspected that fumes are still present, the rescuer should wear an appropriate mask or self-contained breathing apparatus. It may be dangerous to the person providing aid to give mouth-to-mouth resuscitation. Wash contaminated clothing thoroughly with water before removing it, or wear gloves.

See toxicological information (Section 11)

Section 5. Fire-fighting measures

Extinguishing media Suitable extinguishing media	: Use dry chemical, CO ₂ , water spray (fog) or foam.
Unsuitable extinguishing media	: Do not use water jet.
Specific hazards arising from the chemical	: Highly flammable liquid and vapor. In a fire or if heated, a pressure increase will occur and the container may burst, with the risk of a subsequent explosion. Runoff to sewer may create fire or explosion hazard.
Hazardous thermal decomposition products	 Decomposition products may include the following materials: carbon oxides halogenated compounds metal oxide/oxides
Special protective actions for fire-fighters	: Promptly isolate the scene by removing all persons from the vicinity of the incident if there is a fire. No action shall be taken involving any personal risk or without suitable training. Move containers from fire area if this can be done without risk. Use water spray to keep fire-exposed containers cool.
Special protective equipment for fire-fighters	: Fire-fighters should wear appropriate protective equipment and self-contained breathing apparatus (SCBA) with a full face-piece operated in positive pressure mode.

Section 6. Accidental release measures

Personal precautions, protective equipment and emergency procedures

For non-emergency personnel	:	No action shall be taken involving any personal risk or without suitable training. Evacuate surrounding areas. Keep unnecessary and unprotected personnel from entering. Do not touch or walk through spilled material. Shut off all ignition sources. No flares, smoking or flames in hazard area. Do not breathe vapor or mist. Provide adequate ventilation. Wear appropriate respirator when ventilation is inadequate. Put on appropriate personal protective equipment.
For emergency responders	-	If specialized clothing is required to deal with the spillage, take note of any information in Section 8 on suitable and unsuitable materials. See also the information in "For non-emergency personnel".
Environmental precautions	:	Avoid dispersal of spilled material and runoff and contact with soil, waterways, drains and sewers. Inform the relevant authorities if the product has caused environmental pollution (sewers, waterways, soil or air).

Methods and materials for containment and cleaning up

Section 6. Accidental release measures

Small spill	: Stop leak if without risk. Move containers from spill area. Use spark-proof tools and explosion-proof equipment. Dilute with water and mop up if water-soluble. Alternatively, or if water-insoluble, absorb with an inert dry material and place in an appropriate waste disposal container. Dispose of via a licensed waste disposal contractor.
Large spill	: Stop leak if without risk. Move containers from spill area. Use spark-proof tools and explosion-proof equipment. Approach release from upwind. Prevent entry into sewers, water courses, basements or confined areas. Wash spillages into an effluent treatment plant or proceed as follows. Contain and collect spillage with non-combustible, absorbent material e.g. sand, earth, vermiculite or diatomaceous earth and place in container for disposal according to local regulations (see Section 13). Dispose of via a licensed waste disposal contractor. Contaminated absorbent material may pose the same hazard as the spilled product. Note: see Section 1 for emergency contact information and Section 13 for waste disposal.

Section 7. Handling and storage

Precautions for safe handling

Protective measures	Put on appropriate personal protective equipment (see Section 8). Avoid exposure - obtain special instructions before use. Avoid exposure during pregnancy. Do not handle until all safety precautions have been read and understood. Do not get in eyes or on skin or clothing. Do not breathe vapor or mist. Do not ingest. Use only with adequate ventilation. Wear appropriate respirator when ventilation is inadequate. Do not enter storage areas and confined spaces unless adequately ventilated. Keep in the original container or an approved alternative made from a compatible material, kept tightly closed when not in use. Store and use away from heat, sparks, open flame or any other ignition source. Use explosion-proof electrical (ventilating, lighting and material handling) equipment. Use only non-sparking tools. Take precautionary measures against electrostatic discharges. Empty containers retain product residue and can be hazardous. Do not reuse container.
Special precautions	If this material is part of a multiple component system, read the Safety Data Sheet(s) for the other component or components before blending as the resulting mixture may have the hazards of all of its parts.
Advice on general occupational hygiene	Eating, drinking and smoking should be prohibited in areas where this material is handled, stored and processed. Workers should wash hands and face before eating, drinking and smoking. Remove contaminated clothing and protective equipment before entering eating areas. See also Section 8 for additional information on hygiene measures.
Conditions for safe storage, including any incompatibilities	Do not store below the following temperature: 5°C (41°F). Store in accordance with local regulations. Store in a segregated and approved area. Store in original container protected from direct sunlight in a dry, cool and well-ventilated area, away from incompatible materials (see Section 10) and food and drink. Store locked up. Eliminate all ignition sources. Separate from oxidizing materials. Keep container tightly closed and sealed until ready for use. Containers that have been opened must be carefully resealed and kept upright to prevent leakage. Do not store in unlabeled containers. Use appropriate containment to avoid environmental contamination.

Section 8. Exposure controls/personal protection

Control parameters

Occupational exposure limits

Ingredient name	Exposure limits
Solvent naphtha (petroleum), light aliph.	None.
ethanol	ACGIH TLV (United States, 1/2022).
	STEL: 1000 ppm 15 minutes.
	OSHA PEL (United States, 5/2018).
	TWA: 1900 mg/m ³ 8 hours.
	TWA: 1000 ppm 8 hours.
titanium dioxide	OSHA PEL (United States, 5/2018).
	TWA: 15 mg/m ³ 8 hours. Form: Total dust
	ACGIH TLV (United States, 1/2022).
	TWA: 2.5 mg/m ³ 8 hours. Form: respirable
	fraction, finescale particles
butan-1-ol	ACGIH TLV (United States, 1/2022).
	TWA: 20 ppm 8 hours.
	OSHA PEL (United States, 5/2018).
	TWA: 300 mg/m ³ 8 hours.
	TWA: 100 ppm 8 hours.
toluene	OSHA PEL Z2 (United States, 2/2013).
	AMP: 500 ppm 10 minutes.
	CEIL: 300 ppm
	TWA: 200 ppm 8 hours.
	ACGIH TLV (United States, 1/2022).
	Ototoxicant.
vulono	TWA: 20 ppm 8 hours.
xylene	OSHA PEL (United States, 5/2018).
	[Xylenes (o-, m-, p-isomers)]
	TWA: 435 mg/m ³ 8 hours.
	TWA: 100 ppm 8 hours.
	ACGIH TLV (United States, 1/2022). [p-
	xylene and mixtures containing p-xylene]
	Ototoxicant.
	TWA: 20 ppm 8 hours.
aluminium powder (stabilised)	ACGIH TLV (United States, 1/2022).
	[Aluminum, metal and insoluble
	compounds]
	TWA: 1 mg/m ³ 8 hours. Form: Respirable
	fraction
	OSHA PEL (United States, 5/2018).
	TWA: 5 mg/m ³ , (as Al) 8 hours. Form:
	Respirable fraction
	TWA: 15 mg/m³, (as Al) 8 hours. Form: Total
	dust
Stoddard solvent	ACGIH TLV (United States, 1/2022).
	TWA: 525 mg/m ³ 8 hours.
	TWA: 100 ppm 8 hours.
	OSHA PEL (United States, 5/2018).
	TWA: 2900 mg/m ³ 8 hours.
	TWA: 500 ppm 8 hours.

Section 8. Exposure controls/personal protection

4-methylpentan-2-one Otoxicant: TWA: 20 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 435 mg/m 8 hours. TWA: 100 ppm 8 hours. ACGIH TLV (United States, 1/2022). STEL: 75 ppm 15 minutes. TWA: 20 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 410 mg/m 8 hours. TWA: 100 ppm 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption CC = Celling Limit S = Potential skin absorption F = Foundial Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization CC = Celling Limit S = Netential skin absorption F = Foundial Safety and Health Administration. TU = Total dust TVL = Osciptable Maximum Peak SR = Respiratory sensitization SHA = Occupational Safety and Health Administration. TU = Total dust TVL = Total dust TU = Total dust Consult local authorities for acceptable exposure limits. Recommended monitoring : Reference should be made to appropriate monitoring standards. Reference to nationar guidance documents for methods for the determination of hazardous substances will also be required. ppropriate engineering ontrols to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering ontrols also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use	ethylbenzene		ACGIH TLV (United States, 1/2022).
4-methylpentan-2-one TWA: 20 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 435 mg/m* 8 hours. TWA: 100 ppm 8 hours. ACGIH TLV (United States, 1/2022). STEL: 75 ppm 15 minutes. TWA: 20 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 410 mg/m* 8 hours. TWA: 100 ppm 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption CGH = A merican Conference of Governmental Industrial Hygienists. S = Potential skin absorption C = Ceiling Limit S = Stime States, 1/2022). F = Fume STEL = Stom tem Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Total dust DSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Timeshoid Limit Value Drocedures : Weighted Average : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation adiso be required. Dirorbards : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation outper engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering modifications also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Nuironme	5		
4-methylpentan-2-one OSHA PEL (United States, 5/2018). TWA: 435 mg/m³ 8 hours. TWA: 100 ppm 8 hours. ACGIH TLV (United States, 1/2022). STEL: 75 ppm 15 minutes. TWA: 100 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 100 ppm 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption CGIH = Acceptable Maximum Peak S = Potential skin absorption CGIH = Acceptable Maximum Peak S = Potential skin absorption CGIH = Acceptable Maximum Peak S = Potential skin absorption C = Celling Limit S = Skin senstization F = Fourne STEL = Short tem Exposure limit values TPEL = Internal Permissible Exposure Limit TD = Total dust C = Ostipatible TWA = Tome Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart 2 - Toxic and Hazardous Substances TWA = Time Weighted Average Corcedures : IMeretine controls for methods for the determination of hazardous substances outher engineering controls also be required. Ppropriate engineering : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls also be required. prorocedures : Emiss			
4-methylpentan-2-one TWA: 100 ppm 8 hours. TWA: 100 ppm 8 hours. TWA: 20 ppm 8 hours. STEL: 75 ppm 15 minutes. TWA: 20 ppm 8 hours. A = Acceptable Maximum Peak S A = Acceptable Maximum Peak S CGH = American Conference of Governmental Industrial Hygienists. SR C = Celling Limit S F = Fume STEL: 75 short tem Exposure limit values IPEL Internal Peak Z = OSHA 20 CER 1910.1200 Subpart 2 - Toxic and Hazardous Substances Onsult local authorities for acceptable exposure limits. Recommended monitoring C = regineering C = OSHA 20 CER 1910.1200 Subpart 2 - Toxic and Hazardous Substances Onsult local authorities for acceptable exposure limits. Recommended monitoring C = regineering C = Use only with adequate ventilation. Discord duration equipment. Use only with adequate ventilation. Use only with adequate ventilation. Use only with adequate ventilation or work process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below any lower explosive limits. Use explosion-proof ventilation equipment. Nvironmental exposure E Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmenta			
4-methylpentan-2-one TWA: 100 ppm 8 hours. ACGH TLV (United States, 1/2022). STEL: 75 ppm 15 minutes. VWA: 210 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 210 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 210 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 210 ppm 8 hours. TWA: 210 ppm 8 hours. CGH TLV (United States, 5/2018). TWA: 210 ppm 8 hours. CGH TLV (Inited States, 5/2018). TWA: 210 ppm 8 hours. CGIH = American Conference of Governmental Industrial Hygienists. S = Potential skin absorption C = Celling Limit S = Potential skin absorption F = Fume STEL = Shorterm Exposure limit uslues IPEL = Internal Permissible Exposure Limit TD = Total dust R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Orscedures : Reference should be made to appropriate monitoring standards. Reference to national guidec documents for methods for the determination of hazardous substances will also be required. porpopriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statut			
4-methylpentan-2-one ACGH TLV (United States, 1/2022). STEL: 75 ppm 15 minutes. TWA: 20 ppm 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption CGH = American Conference of Governmental Industrial Hygienists. S = Potential skin absorption CGH = Tume SS = Skin sensitization C = Celling Limit SS = Skin sensitization F = Fume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Total dust STH = Cocupational Safety and Health Administration. TUV = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Orrocedures : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. ppropriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Nvironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protect			
STEL: 75 ppm 15 minutes. TWA: 20 ppm 8 hours. OSHA PFL (United States, 5/2018). TWA: 410 mg/m³ 8 hours. TWA: 100 ppm 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption A = Acceptable Maximum Peak S = Potential skin absorption CGIH = American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Celling Limit S = Skin sensitization F = Furme STEL: Short term Exposure limit values DFL = Internal Permissible Exposure Limit TD = Total dust OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Greedenering : Keference should be made to appropriate monitoring standards. Reference to nationar guidance documents for methods for the determination of hazardous substances will also be required. portopriate engineering : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below any lower explosive limits. Use explosion-proof ventilation equipment. entrols : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, furm scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to a	4-methylpentan-2-one		
TWA: 20 ppm 8 hours. OSHA PEL (United States, 5/2018). TWA: 410 mg/m³ 8 hours. TWA: 410 mg/m³ 8 hours. A = Acceptable Maximum Peak S = Potential skin absorption CGH = American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Ceiling Limit SS = Skin sensitization F = Fume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Total dust R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Dorocedures : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. Popropriate engineering : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborme contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. proportiate engineering : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modiffications to the process equipment will be necessary			
Key to abbreviations S A = Acceptable Maximum Peak S CGH American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Celling Limit SR = Respiratory sensitization IPEL = Internal Permissible Exposure Limit STEL = Shot term Exposure limit values IPEL = Internal Permissible Exposure Limit TU = Transhold Limit Value CH = GSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances Time Weighted Average Recommended monitoring : Reference should be made to appropriate monitoring standards. Reference to nationa guidance documents for methods for the determination of hazardous substances will also be required. propriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Protommental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmenta			
TWA: 410 mg/m³ 8 hours. TWA: 100 ppm 8 hours. Key to abbreviations XCGIH = American Conference of Governmental Industrial Hygienists. S Colspan="2">Potential skin absorption XCGIH = American Conference of Governmental Industrial Hygienists. S Colspan="2">Potential skin absorption Colspan="2">Colspan="2"Colspan="2"Colspan="2"Colspan="2"Colspan="2"Colspan="2"Cols			
TWA: 100 ppm 8 hours. Key to abbreviations A = Acceptable Maximum Peak S = Potential skin absorption CGH = American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Ceiling Limit SR = Respiratory sensitization F = Fume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TU = Total dust OSHA = Occupational Safety and Health Administration. TUV = Threshold Limit Value R = Respiratole = Toxic and Hazardous Substances = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart 2 - Toxic and Hazardous Substances = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart 2 - Toxic and Hazardous Substances = Time Weighted Average Corocedures : Reference should be made to appropriate monitoring standards. Reference to national source documents for methods for the determination of hazardous substances will also be required. ppropriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering modi			
Key to abbreviations Key to abbreviations ACGIH = Acceptable Maximum Peak S = Potential skin absorption ACGIH = American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Celling Limit SS = Skin sensitization F = Tume STEL = Short term Exposure limit values DPEL = Internal Permissible Exposure Limit TD = Total dust OSHA = Occupational Safety and Health Administration. TLV = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Broccedures : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. portorplate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below at recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Invironmental exposure : <th></th> <th></th> <th></th>			
A = Acceptable Maximum Peak S = Potential skin absorption ACGIH = Anceptable Maximum Peak S = Respiratory sensitization ACGIH = Anceptable Maximum Peak SR = Respiratory sensitization C = Celling Limit SS = Skin sensitization F = Tume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Time Weighted Average Z OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances = Time Weighted Average Onsult local authorities for acceptable exposure limits. Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. portoriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to accepta			
ACGIH = American Conference of Governmental Industrial Hygienists. SR = Respiratory sensitization C = Celling Limit SR = Skin sensitization C = Celling Limit SR = Skin sensitization F = Fume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Total dust OSHA = Occupational Safety and Health Administration. TUV = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances onsult local authorities for acceptable exposure limits. Recommended monitoring : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. ppropriate engineering : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. nvironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with		Key to abbreviation	
C = Ceiling Limit SS = Skin sensifization F = Fume STEL = Short term Exposure limit values IPEL Internal Permissible Exposure Limit TD = Total dust OSHA = Occupational Safety and Health Administration. TLV = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances = Time Weighted Average onsult local authorities for acceptable exposure limits. Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. ppropriate engineering : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. nvironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures :			•
F = Fume STEL = Short term Exposure limit values IPEL = Internal Permissible Exposure Limit TD = Total dust OSHA = Occupational Safety and Health Administration. TLV = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Onsult local authorities for acceptable exposure limits. Recommended monitoring : Reference should be made to appropriate monitoring standards. Reference to nationa guidance documents for methods for the determination of hazardous substances will also be required. ppropriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. nvironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working peri		f Governmental Industrial Hygienists.	
IPEL = Internal Permissible Exposure Limit TD = Total dust DSHA = Occupational Safety and Health Administration. TU = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Score-construction = Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. Popropriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below and recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash	-		
DSHA = Occupational Safety and Health Administration. TLV = Threshold Limit Value R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average R = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Concedures : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. porpopriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Invironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, furme scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to rem		posure Limit	
R = Respirable TWA = Time Weighted Average Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances TWA = Time Weighted Average Onsult local authorities for acceptable exposure limits. Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. Ppropriate engineering ontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. Invironmental exposure : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.			
Z = OSHA 29 CFR 1910.1200 Subpart Z - Toxic and Hazardous Substances consult local authorities for acceptable exposure limits. Recommended monitoring procedures : Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required. oppropriate engineering pontrols : Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. burnomental exposure ontrols : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location. Eye/face protection : Chemical splash goggles and face shield.			
Recommended monitoring procedures: Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required.opropriate engineering ontrols: Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment.environmental exposure ontrols: Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels.dividual protection measures Hygiene measures: Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection: Chemical splash goggles and face shield.			
Recommended monitoring procedures: Reference should be made to appropriate monitoring standards. Reference to national guidance documents for methods for the determination of hazardous substances will also be required.opropriate engineering ontrols: Use only with adequate ventilation. Use process enclosures, local exhaust ventilation other engineering controls to keep worker exposure to airborne contaminants below an recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment.environmental exposure ontrols: Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels.dividual protection measures Hygiene measures: Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection: Chemical splash goggles and face shield.	Z = OSHA 29 CFR 1910.120	00 Subpart Z - Toxic and Hazardous Substance	-5
ontrols other engineering controls to keep worker exposure to airborne contaminants below an nvironmental exposure recommended or statutory limits. The engineering controls also need to keep gas, vapor or dust concentrations below any lower explosive limits. Use explosion-proof ventilation equipment. : Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures : Hygiene measures : : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location. Eye/face protection :	onsult local authorities for Recommended monitoring	 acceptable exposure limits. Reference should be made to applications. 	propriate monitoring standards. Reference to nation
 Emissions from ventilation or work process equipment should be checked to ensure they comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels. dividual protection measures Hygiene measures Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location. Eye/face protection 	onsult local authorities for Recommended monitoring	 acceptable exposure limits. Reference should be made to ap guidance documents for methods 	propriate monitoring standards. Reference to nation
controlsthey comply with the requirements of environmental protection legislation. In some cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels.dividual protection measures•Hygiene measures•Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection•Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures	 acceptable exposure limits. Reference should be made to ap guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations below 	propriate monitoring standards. Reference to nation for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas,
cases, fume scrubbers, filters or engineering modifications to the process equipment will be necessary to reduce emissions to acceptable levels.dividual protection measures•Hygiene measures••Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection:Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures oppropriate engineering ontrols	 acceptable exposure limits. Reference should be made to ap guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations beloventilation equipment. 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, ow any lower explosive limits. Use explosion-proof
dividual protection measures Hygiene measures : Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location. Eye/face protection : Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols	 acceptable exposure limits. Reference should be made to ap guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations beloventilation ventilation equipment. Emissions from ventilation or wor 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, w any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure
dividual protection measuresHygiene measures: Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection: Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols	 acceptable exposure limits. Reference should be made to ap guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations beloventilation ventilation equipment. Emissions from ventilation or wor they comply with the requirement 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, w any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some
Hygiene measures: Wash hands, forearms and face thoroughly after handling chemical products, before eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location.Eye/face protection: Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols	 acceptable exposure limits. Reference should be made to apply guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or ended to the scrubbers. 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, w any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment
 eating, smoking and using the lavatory and at the end of the working period. Appropriate techniques should be used to remove potentially contaminated clothing. Wash contaminated clothing before reusing. Ensure that eyewash stations and safety showers are close to the workstation location. Eye/face protection : Chemical splash goggles and face shield. 	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols	 acceptable exposure limits. Reference should be made to apply guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or ended to the scrubbers. 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, w any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment
showers are close to the workstation location. Eye/face protection : Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures oppropriate engineering ontrols	 acceptable exposure limits. Reference should be made to apply guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to keel recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or will be necessary to reduce emissions 	propriate monitoring standards. Reference to nation s for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, w any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment
Eye/face protection : Chemical splash goggles and face shield.	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols nvironmental exposure ontrols	 acceptable exposure limits. Reference should be made to apply guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or will be necessary to reduce emiss Wash hands, forearms and face eating, smoking and using the law Appropriate techniques should be 	propriate monitoring standards. Reference to national for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, we any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment sions to acceptable levels.
	onsult local authorities for Recommended monitoring procedures opropriate engineering ontrols nvironmental exposure ontrols	 acceptable exposure limits. Reference should be made to apply guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or will be necessary to reduce emiss Wash hands, forearms and face eating, smoking and using the law Appropriate techniques should be Wash contaminated clothing before 	propriate monitoring standards. Reference to national for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, ow any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment sions to acceptable levels.
	onsult local authorities for Recommended monitoring procedures oppropriate engineering ontrols nvironmental exposure ontrols	 acceptable exposure limits. Reference should be made to ap guidance documents for methods also be required. Use only with adequate ventilation other engineering controls to kee recommended or statutory limits. vapor or dust concentrations belowentilation equipment. Emissions from ventilation or wor they comply with the requirement cases, fume scrubbers, filters or will be necessary to reduce emiss Wash hands, forearms and face eating, smoking and using the law Appropriate techniques should be Wash contaminated clothing befores 	propriate monitoring standards. Reference to nation a for the determination of hazardous substances will n. Use process enclosures, local exhaust ventilation p worker exposure to airborne contaminants below a The engineering controls also need to keep gas, bw any lower explosive limits. Use explosion-proof k process equipment should be checked to ensure s of environmental protection legislation. In some engineering modifications to the process equipment sions to acceptable levels.

United States

Page: 9/19

Product name SILVER GRAY LEAD-FREE

Section 8. Exposure controls/personal protection

Hand protection	: Chemical-resistant, impervious gloves complying with an approved standard should be worn at all times when handling chemical products if a risk assessment indicates this is necessary. Considering the parameters specified by the glove manufacturer, check during use that the gloves are still retaining their protective properties. It should be noted that the time to breakthrough for any glove material may be different for different glove manufacturers. In the case of mixtures, consisting of several substances, the protection time of the gloves cannot be accurately estimated.
Gloves	: polyethylene
Body protection	: Personal protective equipment for the body should be selected based on the task being performed and the risks involved and should be approved by a specialist before handling this product. When there is a risk of ignition from static electricity, wear antistatic protective clothing. For the greatest protection from static discharges, clothing should include anti-static overalls, boots and gloves.
Other skin protection	: Appropriate footwear and any additional skin protection measures should be selected based on the task being performed and the risks involved and should be approved by a specialist before handling this product.
Respiratory protection	: Respirator selection must be based on known or anticipated exposure levels, the hazards of the product and the safe working limits of the selected respirator. If workers are exposed to concentrations above the exposure limit, they must use appropriate, certified respirators. Use a properly fitted, air-purifying or air-fed respirator complying with an approved standard if a risk assessment indicates this is necessary. The respiratory protection shall be in accordance to 29 CFR 1910.134.

Section 9. Physical and chemical properties

Appearance

Solubility(ies)	: pold water	Partially soluble					
	Media	Result					
Density(lbs / gal)	: 8.51						
Relative density	: 1.02	1.02					
Vapor density	: Not available.						
Vapor pressure	: Not available.						
Evaporation rate	: Not available.						
Lower and upper explosive (flammable) limits	: Not available.						
Flammability	: Not available.						
Decomposition temperature	: Not available.	Not available.					
Auto-ignition temperature	: Not available.						
Flash point	: Closed cup: 3.89°C (39°F)					
Boiling point	: >37.78°C (>100°F)						
Melting point	: Not available.						
рН	Not available.						
Odor threshold	Not available.						
Odor	: Not available.						
Color	Not available.						
Physical state	: Liquid.						

Product name SILVER GRAY LEAD-FREE

Section 9. Physical and chemical properties

Partition coefficient: n- octanol/water	: Not applicable.
Viscosity	: Kinematic (40°C (104°F)): >21 mm²/s (>21 cSt)
Volatility	: 72% (v/v), 56.179% (w/w)
% Solid. (w/w)	: 43.821

Section 10. Stability and reactivity

: No specific test data related to reactivity available for this product or its ingredients.
: The product is stable.
: Under normal conditions of storage and use, hazardous reactions will not occur.
: When exposed to high temperatures may produce hazardous decomposition products. Refer to protective measures listed in sections 7 and 8.
: Keep away from the following materials to prevent strong exothermic reactions: oxidizing agents, strong alkalis, strong acids.
: Depending on conditions, decomposition products may include the following materials: carbon oxides halogenated compounds metal oxide/oxides

Section 11. Toxicological information

Information on toxicological effects

Acute toxicity

Product/ingredient name	Result	Species	Dose	Exposure
Solvent naphtha (petroleum), LC50 Inhalation Vapor		Rat	>20 mg/l	4 hours
	LD50 Dermal	Rat	>2000 mg/kg	-
	LD50 Oral	Rat	>5000 mg/kg	-
ethanol	LC50 Inhalation Vapor	Rat	124700 mg/m ³	4 hours
	LD50 Dermal	Rat	17100 mg/kg	-
	LD50 Oral	Rat	7 g/kg	-
titanium dioxide	LC50 Inhalation Dusts and mists	Rat	>6.82 mg/l	4 hours
	LD50 Dermal	Rabbit	>5000 mg/kg	-
	LD50 Oral	Rat	>5000 mg/kg	-
butan-1-ol	LC50 Inhalation Vapor	Rat	24000 mg/m ³	4 hours
	LD50 Dermal	Rabbit	3400 mg/kg	-
	LD50 Oral	Rat	790 mg/kg	-
toluene	LC50 Inhalation Vapor	Rat	49 g/m³	4 hours
	LD50 Dermal	Rabbit	8.39 g/kg	-
	LD50 Oral	Rat	5580 mg/kg	-
xylene	LD50 Dermal	Rabbit	1.7 g/kg	-
	LD50 Oral	Rat	4.3 g/kg	-
aluminium powder (stabilised)	LC50 Inhalation Dusts and mists	Rat	>5 mg/l	4 hours
	1	1	United States	Page: 10/19

Product name SILVER GRAY LEAD-FREE

Section 11. Toxicological information

	LD50 Oral	Rat	>15900 mg/kg	-	
Stoddard solvent	LD50 Oral	Rat	>5 g/kg	-	
ethylbenzene	LC50 Inhalation Vapor	Rat	17.8 mg/l	4 hours	
	LD50 Dermal	Rabbit	17.8 g/kg	-	
	LD50 Oral	Rat	3.5 g/kg	-	
4-methylpentan-2-one	LC50 Inhalation Vapor	Rat	11 mg/l	4 hours	
	LD50 Dermal	Rabbit	>5000 mg/kg	-	
	LD50 Oral	Rat	2.08 g/kg	-	

Conclusion/Summary

: There are no data available on the mixture itself.

Irritation/Corrosion

Product/ingredient name	Result	Species	Score	Exposure	Observation
x ylene	Skin - Moderate irritant	Rabbit	-	24 hours 500 mg	-

Conclusion/Summary				
Skin	1	There are	e no data a	vailable on the mixture itself.
Eyes	1	There are	e no data a	vailable on the mixture itself.
Respiratory	1	There are	e no data a	vailable on the mixture itself.
Sensitization				
Conclusion/Summary				
Skin	1	There are	e no data a	vailable on the mixture itself.
Respiratory	:	There are	e no data a	vailable on the mixture itself.
Mutagenicity				
Conclusion/Summary	1	There are	e no data a	vailable on the mixture itself.
Carcinogenicity				
Conclusion/Summary	:	There are	e no data a	vailable on the mixture itself.
Classification				
Product/ingredient name	(OSHA	IARC	NTP

Product/ingredient name	OSHA	IARC	NTP
titanium dioxide	-	2B	-
toluene	-	3	-
xylene	-	3	-
ethylbenzene	-	2B	-
4-methylpentan-2-one	-	2B	-

Carcinogen Classification code:

IARC: 1, 2A, 2B, 3, 4 NTP: Known to be a human carcinogen; Reasonably anticipated to be a human carcinogen OSHA: + Not listed/not regulated: -

Reproductive toxicity

Conclusion/Summary	: There are no data available on the mixture itself.
Teratogenicity	
Conclusion/Summary	: There are no data available on the mixture itself.
Specific target organ toxicit	<u>y (single exposure)</u>

Section 11. Toxicological information

Name		Route of exposure	Target organs
Solvent naphtha (petroleum), light aliph.	Category 3	-	Narcotic effects
butan-1-ol	Category 3	-	Respiratory tract irritation
	Category 3		Narcotic effects
toluene	Category 3	-	Narcotic effects
xylene	Category 3	-	Respiratory tract irritation
4-methylpentan-2-one	Category 3	-	Narcotic effects

Specific target organ toxicity (repeated exposure)

Name	Category	Route of exposure	Target organs
toluene Stoddard solvent	Category 2 Category 1	-	- central nervous system (CNS)
ethylbenzene	Category 2	-	hearing organs

Target organs

: Contains material which causes damage to the following organs: brain, eye, lens or cornea.

Contains material which may cause damage to the following organs: blood, kidneys, lungs, the nervous system, the reproductive system, liver, heart, upper respiratory tract, skin, central nervous system (CNS), ears, testes.

Aspiration hazard

Name	Result
Solvent naphtha (petroleum), light aliph.	ASPIRATION HAZARD - Category 1
toluene	ASPIRATION HAZARD - Category 1
xylene	ASPIRATION HAZARD - Category 1
Stoddard solvent	ASPIRATION HAZARD - Category 1
ethylbenzene	ASPIRATION HAZARD - Category 1

Information on the likely routes of exposure

Potential acute health effects

Eye contact	: Causes serious eye damage.
Inhalation	: Can cause central nervous system (CNS) depression. May cause drowsiness or dizziness.
Skin contact	: Causes skin irritation. Defatting to the skin.
Ingestion	: Can cause central nervous system (CNS) depression.
Over-exposure signs/sympt	o <u>ms</u>
Eye contact	: Adverse symptoms may include the following: pain watering redness

Section 11. Toxicological information

Inhalation	: Adverse symptoms may include the following:
	nausea or vomiting
	headache
	drowsiness/fatigue
	dizziness/vertigo
	unconsciousness
	reduced fetal weight
	increase in fetal deaths
	skeletal malformations
Skin contact	
Skin contact	: Adverse symptoms may include the following:
	pain or irritation
	redness
	dryness
	cracking
	blistering may occur
	reduced fetal weight
	increase in fetal deaths
	skeletal malformations
Ingestion	: Adverse symptoms may include the following:
	stomach pains
	reduced fetal weight
	increase in fetal deaths
	skeletal malformations
Delayed and immediate eff	ects and also chronic effects from short and long term exposure
Conclusion/Summary	: There are no data available on the mixture itself. This product contains TiO2 which has
	been classified as a GHS Carcinogen Category 2 based on its IARC 2B classification.
	For many products, TiO2 is utilized as a raw material in a liquid coating formulation. In
	this case, the TiO2 particles are bound in a matrix with no meaningful potential for
	human exposure to unbound particles of TiO2 when the product is applied with a brush
	or roller. Sanding the coating surface or mist from spray applications may be harmful
	depending on the duration and level of exposure and require the use of appropriate
	personal protective equipment and/or engineering controls (see Section 8). Acrylate
	components of the mixture have irritating properties. Prolonged or repeated contact
	with skin or mucous membrane may result in irritation symptoms, such as redness,
	blistering, dermatitis etc. May cause allergic skin reactions with repeated exposure.
	The inhalation of airborne droplets or aerosols may cause irritation of the respiratory
	tract. Ingestion may cause nausea, weakness and central nervous system effects.
	Exposure to component solvent vapor concentrations in excess of the stated
	occupational exposure limit may result in adverse health effects such as mucous
	membrane and respiratory system irritation and adverse effects on the kidneys, liver
	and central nervous system. Symptoms and signs include headache, dizziness, fatigue,
	muscular weakness, drowsiness and, in extreme cases, loss of consciousness.
	Solvents may cause some of the above effects by absorption through the skin. There is
	some evidence that repeated exposure to organic solvent vapors in combination with
	constant loud noise can cause greater hearing loss than expected from exposure to
	noise alone. If splashed in the eyes, the liquid may cause irritation and reversible
	damage. This takes into account, where known, delayed and immediate effects and
	also chronic effects of components from short-term and long-term exposure by oral,
	inhalation and dermal routes of exposure and eye contact.
Short term exposure	
Potential immediate	: There are no data available on the mixture itself.
effects	

Section 11. Toxicological information

Potential delayed effects	: There are no data available on the mixture itself.
<u>Long term exposure</u>	
Potential immediate effects	: There are no data available on the mixture itself.
Potential delayed effects	: There are no data available on the mixture itself.
Potential chronic health eff	ects
General	: Causes damage to organs through prolonged or repeated exposure. Prolonged or repeated contact can defat the skin and lead to irritation, cracking and/or dermatitis.
Carcinogenicity	: Suspected of causing cancer. Risk of cancer depends on duration and level of exposure.
Mutagenicity	: No known significant effects or critical hazards.
Reproductive toxicity	: Suspected of damaging fertility or the unborn child.

Numerical measures of toxicity

Acute toxicity estimates

Product/ingredient name	Oral (mg/ kg)	Dermal (mg/kg)	Inhalation (gases) (ppm)	Inhalation (vapors) (mg/l)	Inhalation (dusts and mists) (mg/ I)
SILVER GRAY LEAD-FREE	6881.3	8630.3	N/A	242.4	33.1
Solvent naphtha (petroleum), light aliph.	N/A	2500	N/A	N/A	N/A
ethanol	7000	17100	N/A	124.7	N/A
butan-1-ol	790	3400	N/A	24	N/A
toluene	5580	8390	N/A	49	N/A
xylene	4300	1700	N/A	11	1.5
ethylbenzene	3500	17800	N/A	17.8	1.5
4-methylpentan-2-one	2080	N/A	N/A	11	1.5

Section 12. Ecological information

Toxicity

Product/ingredient name	Result	Species	Exposure
e thanol	Acute EC50 7640 mg/l Fresh water	Daphnia - Daphnia magna	48 hours
titanium dioxide	Acute LC50 >100 mg/l Fresh water	Daphnia - Daphnia magna	48 hours
butan-1-ol	Acute LC50 1376 mg/l	Fish	96 hours
ethylbenzene	Acute EC50 1.8 mg/l Fresh water	Daphnia	48 hours
-	Chronic NOEC 1 mg/l Fresh water	Daphnia - Ceriodaphnia dubia	-
4-methylpentan-2-one	Acute LC50 >179 mg/l	Fish	96 hours

Persistence and degradability

Product/ingredient name	Test	Result	Dose	Inoculum
ethylbenzene 4-methylpentan-2-one		79 % - Readily - 10 days 83 % - Readily - 28 days	-	-

United States Pa

Section 12. Ecological information

Product/ingredient name	Aquatic half-life	Photolysis	Biodegradability
ethanol	-	-	Readily
toluene	-	-	Readily
xylene	-	-	Readily
ethylbenzene	-	-	Readily
4-methylpentan-2-one	-	-	Readily

Bioaccumulative potential

Product/ingredient name	LogPow	BCF	Potential
ethanol	-0.35	-	Low
butan-1-ol	1	-	Low
toluene	2.73	8.32	Low
xylene	3.12	7.4 to 18.5	Low
Stoddard solvent	3.16 to 7.06	-	High
ethylbenzene	3.6	79.43	Low
4-methylpentan-2-one	1.9	-	Low

Mobility in soil

Soil/water partition coefficient (Koc)

: Not available.

Section 13. Disposal considerations

```
Disposal methods
```

: The generation of waste should be avoided or minimized wherever possible. Disposal of this product, solutions and any by-products should at all times comply with the requirements of environmental protection and waste disposal legislation and any regional local authority requirements. Dispose of surplus and non-recyclable products via a licensed waste disposal contractor. Waste should not be disposed of untreated to the sewer unless fully compliant with the requirements of all authorities with jurisdiction. Waste packaging should be recycled. Incineration or landfill should only be considered when recycling is not feasible. This material and its container must be disposed of in a safe way. Care should be taken when handling emptied containers that have not been cleaned or rinsed out. Empty containers or liners may retain some product residues. Vapor from product residues may create a highly flammable or explosive atmosphere inside the container. Do not cut, weld or grind used containers unless they have been cleaned thoroughly internally. Avoid dispersal of spilled material and runoff and contact with soil, waterways, drains and sewers.

Disposal should be in accordance with applicable regional, national and local laws and regulations. Refer to Section 7: HANDLING AND STORAGE and Section 8: EXPOSURE CONTROLS/PERSONAL PROTECTION for additional handling information and protection of employees. Section 6. Accidental release measures

14. Transport information

	DOT	IMDG	ΙΑΤΑ
UN number	UN1263	UN1263	UN1263
UN proper shipping name	PAINT	PAINT	PAINT
Transport hazard class (es)	3	3	3
Packing group	II	II	П
Environmental hazards	No.	No.	No.
Marine pollutant substances	Not applicable.	Not applicable.	Not applicable.
Product RQ (lbs)	2203.9	Not applicable.	Not applicable.
RQ substances	(xylene, toluene)	Not applicable.	Not applicable.

Additional information

DOT	 Package sizes shipped in quantities less than the product reportable quantity are not subject to the RQ (reportable quantity) transportation requirements.
IMDG	: None identified.
ΙΑΤΑ	: None identified.

Special precautions for user : Transport within user's premises: always transport in closed containers that are upright and secure. Ensure that persons transporting the product know what to do in the event of an accident or spillage.

Transport in bulk according : Not applicable. to IMO instruments

Section 15. Regulatory information

United States

United States inventory (TSCA 8b) : All components are active or exempted.

SARA 302/304

SARA 304 RQ : Not applicable.

Composition/information on ingredients

No products were found.

SARA 311/312

TOXIC TO REPRODUCTION - Category 2 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3 SPECIFIC TARGET ORGAN TOXICITY (REPEATED EXPOSURE) - Category 1	Classification	: FLAMMABLE LIQUIDS - Category 2 SKIN IRRITATION - Category 2 SERIOUS EYE DAMAGE - Category 1 CARCINOGENICITY - Category 2
		SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3

United States Page: 16/19

Section 15. Regulatory information

HNOC - Defatting irritant

Composition/information on ingredients

Name	%	Classification
Solvent naphtha (petroleum), light aliph.	≥10 - ≤20	SKIN IRRITATION - Category 2 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3 ASPIRATION HAZARD - Category 1
ethanol	≥10 - ≤20	HNOC - Defatting irritant FLAMMABLE LIQUIDS - Category 2 EYE IRRITATION - Category 2A HNOC - Defatting irritant
titanium dioxide butan-1-ol	≥10 - ≤20 ≥10 - ≤14	CARCINOGENICITY - Category 2 FLAMMABLE LIQUIDS - Category 3 ACUTE TOXICITY (oral) - Category 4 SKIN IRRITATION - Category 2 SERIOUS EYE DAMAGE - Category 1 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Respiratory tract irritation) - Category 3 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3 HNOC - Defatting irritant
toluene	≥5.0 - ≤10	FLAMMABLE LIQUIDS - Category 2 SKIN IRRITATION - Category 2 TOXIC TO REPRODUCTION - Category 2 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Narcotic effects) - Category 3 SPECIFIC TARGET ORGAN TOXICITY (REPEATED EXPOSURE) - Category 2 ASPIRATION HAZARD - Category 1 HNOC - Defatting irritant
xylene	≥1.0 - ≤5.0	FLAMMABLE LIQUIDS - Category 3 ACUTE TOXICITY (dermal) - Category 4 ACUTE TOXICITY (inhalation) - Category 4 SKIN IRRITATION - Category 2 EYE IRRITATION - Category 2A SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE) (Respiratory tract irritation) - Category 3 ASPIRATION HAZARD - Category 1
Stoddard solvent	≥1.0 - ≤5.0	FLAMMABLE LIQUIDS - Category 3 EYE IRRITATION - Category 2A SPECIFIC TARGET ORGAN TOXICITY (REPEATED EXPOSURE) - Category 1 ASPIRATION HAZARD - Category 1 HNOC - Defatting irritant
ethylbenzene	<1.0	FLAMMABLE LIQUIDS - Category 2 ACUTE TOXICITY (inhalation) - Category 4 CARCINOGENICITY - Category 2 SPECIFIC TARGET ORGAN TOXICITY (REPEATED EXPOSURE) - Category 2 ASPIRATION HAZARD - Category 1 HNOC - Defatting irritant
		United States Page: 17/19

Product name SILVER GRAY LEAD-FREE

Section 15. Regulatory information

•		
4-methylpentan-2-one	<1.0	FLAMMABLE LIQUIDS - Category 2 ACUTE TOXICITY (inhalation) - Category 4 EYE IRRITATION - Category 2A CARCINOGENICITY - Category 2 SPECIFIC TARGET ORGAN TOXICITY (SINGLE EXPOSURE)
		(Narcotic effects) - Category 3 HNOC - Defatting irritant

SARA 313

	Chemical name	<u>CAS number</u>	Concentration
Supplier notification	: butan-1-ol	71-36-3	7 - 13
	toluene	108-88-3	3 - 7
	xylene	1330-20-7	1 - 5
	Aluminium powder (stabilized)	7429-90-5	1 - 5
	ethylbenzene	100-41-4	0.1 - 1
	4-methylpentan-2-one	108-10-1	0.1 - 1

SARA 313 notifications must not be detached from the SDS and any copying and redistribution of the SDS shall include copying and redistribution of the notice attached to copies of the SDS subsequently redistributed.

Additional environmental information is contained on the Environmental Data Sheet for this product, which can be obtained from your PPG representative.

California Prop. 65

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

Section 16. Other information

Hazardous Material Information System (U.S.A.)

Health : 3 * Flammability : 3 Physical hazards : 0

(*) - Chronic effects

Caution: HMIS® ratings are based on a 0-4 rating scale, with 0 representing minimal hazards or risks, and 4 representing significant hazards or risks. Although HMIS® ratings and the associated label are not required on MSDSs or products leaving a facility under 29 CFR 1910.1200, the preparer may choose to provide them. HMIS® ratings are to be used with a fully implemented HMIS® program. HMIS® is a registered trademark and service mark of the American Coatings Association, Inc.

The customer is responsible for determining the PPE code for this material. For more information on HMIS® Personal Protective Equipment (PPE) codes, consult the HMIS® Implementation Manual.

National Fire Protection Association (U.S.A.)

Health : 3 Flamma Date of previous issue	ability : 3 Instability : 0 : 6/1/2021
Organization that prepared the SDS	: EHS
Key to abbreviations	: ATE = Acute Toxicity Estimate BCF = Bioconcentration Factor GHS = Globally Harmonized System of Classification and Labelling of Chemicals IATA = International Air Transport Association IBC = Internediate Bulk Container IMDG = International Maritime Dangerous Goods LogPow = logarithm of the octanol/water partition coefficient MARPOL = International Convention for the Prevention of Pollution From Ships, 1973 as modified by the Protocol of 1978. ("Marpol" = marine pollution)

United States Page: 18/19

Product name SILVER GRAY LEAD-FREE

Section 16. Other information

N/A = Not available SGG = Segregation Group UN = United Nations

Indicates information that has changed from previously issued version.

Disclaimer

The information contained in this data sheet is based on present scientific and technical knowledge. The purpose of this information is to draw attention to the health and safety aspects concerning the products supplied by PPG, and to recommend precautionary measures for the storage and handling of the products. No warranty or guarantee is given in respect of the properties of the products. No liability can be accepted for any failure to observe the precautionary measures described in this data sheet or for any misuse of the products.