

# **AD 2341** 1.975.2341

## ANTISILICONIC ADDITIVE

AD 2341 contains specific surface coating modifiers and is designed for use when fisheye contamination of topcoat becomes evident.



#### **PREPARATION**

Add to DURALIT CAR, DURALIT ABF, Clear 0500, MS Clear 0440, HS Clear 0200, UHS CLEARS, UHS DURALIT EXTRA and HP Clear by 0.5 - 2% volume.

#### Important:

This product should be added after activation but before thinning to ensure that he maximum VOC for the product in use is not exceeded. Thinner is then topped up to the normal recommended level.

Never add to primers and fillers. Do not exceed recommended addition.

#### USE

Apply modified topcoat in mist coats until defects disappear. If needed, allow topcoat to dry, sand, degrease with 3600 Degreaser, then recoat.



# TECHNICAL DATA

0.5 Ltr Pack size:

Storage: Store in a cool dry place away from heat.



## **VOC INFORMATION**

This product falls outside of the scope of EU Directive 2004/42 and therefore does not have a VOC product category classification.

This product can be used by professional motor vehicle repairers.

## SAFETY AND HANDLING

These products are for professional use only and are not to be used for purposes other than those specified. The information on this TDS is based on present scientific and technical knowledge, and it is the responsibility of the user to take all necessary steps in order to ensure the suitability of the product for the intended purpose.



For Health and Safety information, please refer to the material Safety Data Sheet, also available at: www.maxmever.com

#### For further information please contact:

PPG Industries (UK) Limited, MaxMever Division Customer Service & Sales Group, Needham Road, Stowmarket, Suffolk. IP14 2AD, England. Tel: 01449 771779 Fax: 01449 773495

MaxMeyer and the MaxMeyer logo are trademarks of PPG industries. © 2011 PPG Industries. All rights reserved.

