

# **SPEEDHIDE®**

**Architectural Coatings** 

## **GENERAL DESCRIPTION**

PPG Speedhide zero VOC\* Interior Latex is a professional grade interior paint formulated to meet the performance requirements of professional applicators. PPG Speedhide provides excellent hide, great touch-up, easy application, and provides a mold and mildew resistant coating. This zero VOC\*, low odor paint is ideal for painting occupied spaces while delivering the durable product performance required. Recommended for interior walls, ceilings, and trim where a consistent finish is desirable.

\*Colorants added to this base paint may increase VOC level significantly depending on color choice.

## RECOMMENDED SUBSTRATES

Concrete/Masonry Gypsum Wallboard-Drywall

Concrete Block (CMU) Plaster Ferrous Metal Wood

# CONFORMANCE STANDARDS

VOC compliant in all regulated areas **Pending** MPI approval categories 44+

+Pending February 2024 approvals

#### PRODUCT INFORMATION

6-4101ZV White & Pastel Base

Refer to the appropriate color formula book, automatic tinting equipment, and or computer color matching system for color formulas and tinting instructions.

## **PACKAGING**

1-Gallon (3.78 L) 5-Gallon (18.9 L) PPG Speedhide zero VOC Interior Latex Paint Low-Sheen Eggshell

## PRODUCT DATA

PRODUCT TYPE: Vinyl Acrylic Latex SHEEN: Eggshell, 20-30 @85°

**VOLUME SOLIDS:** 37% +/- 2% **WEIGHT SOLIDS:** 54% +/- 2%

**WEIGHT/GALLON:** 11.4 lbs. (5.2 kg) +/- 0.2 lbs. (91 g)

**VOC:** 0 g/L (0.0 lbs./gal.)\*

\*Colorants added to this base paint may increase VOC level significantly depending on color choice.

**COVERAGE:** Up to 400 sq. ft. (37 sq. meters) per U.S. Gallon (3.78L) on smooth, nonporous surfaces.

Wet Film Thickness: 4.0 mils
Wet Microns: 102
Dry Film Thickness: 1.5 mils
Dry Microns: 38

Coverage figures do not include loss due to surface irregularities and porosity or material loss due to application method or mixing. Some colors, drastic color changes, or porous substrates may require more than one coat to achieve a uniform finish.

**DRYING TIME:** Dry time @ 77°F (25°C); 50% relative humidity.

To Touch: 30-60 minutes
To Recoat: 2-4 hours
To Full Cure: 30 days

Drying times listed may vary depending on temperature, humidity, film build, color, and air movement. Wait at least 30 days after painting before cleaning the surface with a non-abrasive, mild cleanser. Very deep colors may require longer to fully cure.

CLEANUP: Clean tools with warm, soapy water.

**DISPOSAL:** Contact your local environmental regulatory agency for guidance on disposal of unused product. Do not pour down a drain or storm sewer.

FLASH POINT: Over 200°F (93°C)

## FEATURES / BENEFITS

#### **Features**

Excellent Hiding & Coverage 0 g/L VOC\* Low Odor Good Burnish Resistance Great Film Build & Sag Resistance Great Touch-Up Mildew Resistant

#### **Benefits**

Saves money; less material required
Meets the most stringent environmental regulations
Ideal for painting in occupied spaces
Shine free finish at the site of washing
Resists runs and drips on the wall
Reduces the amount of rework
Resists mold and mildew on the dry paint film

\*Colorants added to this base paint may increase VOC level significantly depending on color choice.

Read Label and Safety Data Sheet prior to use. See other cautions on last page.

Speedhide 6-4101ZV

**Architectural Coatings** 

PPG Speedhide zero VOC Interior Latex Paint Low-Sheen Eggshell

## **GENERAL SURFACE PREPARATION**

Surface must be clean and dry. Remove all loose, peeling paint, dirt, grease, and any other surface contaminants. Putty all nail holes and caulk all cracks and open seams. Sand all glossy, rough, and patched surfaces. Plaster, concrete, and masonry surfaces must be completely dry, free of efflorescence, and allowed to cure for 30 days prior to painting. Prime all bare wood, drywall, plaster, masonry, metal, and porous surfaces with an appropriate PPG primer.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust or fumes. LEAD IS TOXIC. EXPOSURE TO LEAD DUST OR FUMES CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a properly fitted NIOSH-approved respirator and prevent skin contact to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the USEPA National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead. Follow these instructions to control exposure to other hazardous substances that may be released during surface preparation.

**CONCRETE/MASONRY:** New concrete and masonry should cure for at least 30 days and preferably 90 days prior to priming and painting. The pH of the substrate must be less than 10 before priming. Use of an alkali resistant primer is recommended.

**CONCRETE BLOCK (CMU):** Mortar should cure for at least 30 days and preferably 90 days prior to painting. Fill block with an appropriate block filler.

**FERROUS METAL**: The surface must be cleaned thoroughly to remove any dust, rust, and surface contaminants, and then primed with a metal primer.

**GYPSUM WALLBOARD-DRYWALL:** Nails or screws should be countersunk, and they along with any indentations should be mudded flush with the surface, sanded smooth and cleaned to remove any dust prior to priming the substrate.

**PLASTER:** Plaster, hardcoat, skim coat, or other alkaline surfaces should be allowed to cure for at least 30 days prior to priming and painting. The pH of the substrate must be less than 10 before priming. Use of an alkali resistant primer is recommended.

**WOOD:** Countersink all nails, putty flush with surface. Unpainted wood or wood in poor condition should be sanded smooth, wiped clean, then primed. Any knots or resinous areas must be sealed before painting.

#### RECOMMENDED PRIMERS

Concrete/Masonry 4-603XI, 17-921XI
Concrete Block (CMU) 6-7, 6-15XI
Ferrous Metal 4020, 4360

Gypsum Wallboard-Drywall 6-2, 6-4, 9-900, 12-900XI,

17-921XI

Plaster 4-603XI, 17-921XI

Wood 6-2, 9-900, 12-900XI, 17-921XI

## LIMITATIONS OF USE

FOR INTERIOR USE ONLY. Apply when air, product and surface temperatures are between 50°F (10°C) and 90°F (32°C).

Not recommended for use on floors.

PROTECT FROM FREEZING.

Speedhide 6-4101ZV

**Architectural Coatings** 

PPG Speedhide zero VOC Interior Latex Paint Low-Sheen Eggshell

## APPLICATION INFORMATION

Stir thoroughly before using and occasionally when in use. When using more than one can of the same color, intermix to ensure color uniformity. USE WITH ADEQUATE VENTILATION. KEEP OUT OF REACH OF CHILDREN. Read all label and Safety Data Sheet (SDS) information prior to use. SDS are available through our web site or by calling 1-800-441-9695.

**Application Equipment:** Apply with a high-quality brush, roller, paint pad, or by spray equipment. Where necessary, apply a second coat and allow each coat to dry thoroughly before applying the next coat.

**Airless Spray**: Pressure 1500 to 2000 psi; tip 0.015" to 0.021". Spray equipment must be handled with due care and in accordance with manufacturer's recommendation. High-pressure injection of coatings into the skin by airless equipment may cause serious injury.

Brush: Polyester/Nylon Brush Roller (nap roller cover): 3/8" - 3/4"

**Thinning:** Do not thin.

### Permissible temperatures during application:

 Material:
 50 to 90°F
 10 to 32°C

 Ambient:
 50 to 90°F
 10 to 32°C

 Substrate:
 50 to 90°F
 10 to 32°C

## **PRECAUTIONS**

WARNING! HARMFUL IF INHALED. HARMFUL IF SWALLOWED. Do not breathe vapor or mist. Do not swallow. Keep container tightly closed and sealed until ready for use. Wash thoroughly after handling. Provide fresh air ventilation during and after application and drying. Avoid the inhalation of dust, particulates, spray or mist arising from the application of this preparation. Use personal protective equipment as required. Prior to use, read and follow product-specific SDS and label information. FIRST AID: If swallowed, rinse mouth with water (only if the person is conscious). Call physician immediately. Do not induce vomiting unless directed to do so by medical personnel. If in eyes, rinse with water for 15 minutes. Check for and remove any contact lenses. If on skin, rinse well with water. Wash with soap and water. Get medical attention if irritation develops. If inhaled, remove to fresh air. Call physician immediately. Contains isothiazolinones. May cause allergic reaction. Keep out of the reach of children. For workplace use, an SDS is available from your retailer or by calling (412) 492-5555. EMERGENCY SPILL INFORMATION: (412) 434-4515 (U.S.).

© 2023 PPG Industries, Inc. All Rights Reserved. The PPG Logo is a registered trademark and PPG is a trademark of PPG Industries Ohio, Inc. Speedhide is a registered trademark of PPG Architectural Finishes. Inc.

PPG Architectural Finishes, Inc. believes the technical data presented is currently accurate: however, no guarantee of accuracy, comprehensiveness, or performance is given or implied. Improvements in coatings technology may cause future technical data to vary from what is in this bulletin. For complete, up-to-date technical information, call 1-800-441-9695.

