



Technical Information

TB011

"Pouring Off" Toners

It has been our policy not to recommend "pour-offs" of PPG toners due to the risk of contamination or inaccurate labeling. However, we do understand our distributors may need to engage in this practice when servicing the Mobile Touch-up market.

To insure accurate labeling and minimize contamination, the following procedures are recommended only for servicing the Mobile Touch-up market.

1. A Barex 25 bottle must be used:
 - Bottle is DOX461
 - Lid is DOX462
2. A special DMD 8oz. label must be used (these labels are available for lead and non-lead products):
 - DMD-1 label form number 5793-1, LDMD8Z-1
 - DMD-2 label form number 5793-2, LDMD8Z-2

Note: To maintain color and consistency toner must be properly agitated prior to "pouring off".

Bottles and labels are currently only available from our Lima Warehouse.

