



EB-750CAN 02/13

Product Information

EC750 One-Visit™ Appearance Clearcoat

Product Description

EC750 is a high gloss, high solids appearance clearcoat designed specifically for use with Envirobase® High Performance. The One-Visit™ Appearance Clearcoat, with zero flash time, reduces cycle times while maintaining the quality and appearance required by high production shops. From an environmental standpoint, the low 2.1 VOC of EC750 along with the high solids resin also decreases clearcoat material usage and therefore greatly reduces the overall VOC emissions.

Preparation of Substrate:



In all cases, wash all surfaces to be painted with soap and water, then apply the appropriate Global or OneChoice[®] cleaner. Ensure that the substrate is thoroughly cleaned and dried both before and after application work.



Wet sand with U.S. 500-600 / European P800-1200 grade paper or dry sanding with U.S. 400-500 / European P600-800 grade paper.



Wash off residue and dry thoroughly before re-cleaning with appropriate Global or OneChoice[®] substrate cleaner. The use of a SX1070 tack rag is recommended.

© 2013 PPG Industries

APPLICATION GUIDE:

Mixing Ratio:



 EC750
 4 vols

 ECH70xx
 1 vol

 D87xx
 *vol



Pot life* @ 68°F / 20°C 2.5 - 3 hours

*Note: Pot life will be shortened with increased temperatures.

*Note: For the standard two coat application method, ½ part of D87xx thinner may be added to the mix to improve flow if needed.

Use the tables to determine the proper hardener needed for the application.

Hardener Selection

Thinner Selection

ECH7070: Fast Hardener

55° - 75°F (13° - 24°C)

ECH7080: Medium Hardener

75° - 95°F (24° - 35°C)

ECH7090: Slow Hardener

95°F and above (35°C)

Hardener selection may be dependent on the size of repair.

Optional Additive:

SLV814 Universal flexiblizer may be used to flex EC750



EC750: 4 vols ECH70XX: 1 vol SI V814 · 10%

When used on plastic parts, EC750 does not require the use of SLV814 Universal flexibilizer. However, for very flexible or leading edge parts such as bumper covers and fascias, the addition of SLV814 will improve overall flexibility.

Spraygun set-up:



Fluid Tip 1.2 - 1.4

Spray Viscosity 17-19 secs DIN 4 @ 20°C / 68°F

Spray pressure:

HVLP at air cap Max. 10 psi

Refer to the manufacturers gun recommendations for air pressure

Number of coats:



One-Visit: Apply 1 light to medium flowing coat immediately followed by a second medium coat to give 2 mils dry film thickness.

Standard 2-Coat: Apply 2 single medium wet coats allowing a 5 -10 minute flash time between each coat, to provide for 2 to 2.5 mils dry film thickness.

Flash off at 68°F/20°C:



One-Visit: Allow 1 minute of flash time between the 1st and 2nd coats. For 2 or more panels, no flash time between coats is required.

Standard 2-Coat: Allow 5 -10 minute flash off between coats depending on your spray booth conditions and / or hardener choice.

Drying Times:

Dust-free 68%/20%50-60 minutesDry to handle 68%/20%OvernightAir Dry 68%/20%OvernightForce Dry 140%/60%30 minutesMetal Temperature*OvernightTape Time 68%/20%OvernightIR (Infrared)8-15 minutes

^{*}All force dry times are quoted for metal temperature. Additional time must be allowed during force dry to allow metal to reach recommended temperature.

Cumulative Parts Mix by Weight Activation Chart for EC750 One-Visit™ Appearance Clearcoat 4:1

Clearcoat Required	EC750 Clearcoat Parts ECH70xx Hardener Parts	
¹ / ₄ Pint / 4 oz.	126.3	154.8
½ Pint / 8 oz.	252.5	309.5
¾ Pint / 12 oz.	378.8	464.3
1 Pint / 16 oz.	505.0	619.0
1.5 Pints / 20 oz.	631.3	773.8
1.75 Pints / 28 oz.	883.8	1083.3
1 Quart / 32 oz.	1010.1	1238.1
1.5 Quarts / 40 oz.	1262.6	1547.6
2 Quarts / 64 oz.	2020.2	2476.2

APPLICATION GUIDE:

Overcoat/Recoat

€**}**

Overcoat/Recoat Time

12-16 hours at 68°F/20°C air dry or after force dry cool down. EC750 must be sanded

before recoating with primer, color or clear.

2

Grade wet U.S. 500 – 600 / European P800 - 1200

Grade dry U.S. 400 – 500 / European P600 - 800

7

Overcoat with Envirobase® High Performance Basecoat



Polishing

Polishing is not normally required. If, however, polishing is required to remove minor dirt nibs, wet sand with P1500 wet and follow normal polishing procedures.

Performance Guidelines

Allow the Envirobase[®] High Performance Waterborne Basecoat to flash off for 15 minutes (but no longer than 24 hours) before applying EC750. If basecoat dries longer than 24 hours, additional basecoat must be applied before clearcoating. The timing will depend on thickness and temperature.

Recoating times will be extended at lower temperatures. EC750 may be sanded with 1200 grit paper or finer and polished when hard, to rectify minor imperfections.

Fading Out EC750


After spot repairing, Use OneChoice® SXA840 blending solvent and apply starting from the outside of the repair moving towards the center of the repaired area to lose the clearcoat blend edge.

Technical Data

Total dry film build:

Minimum2.0 milsMaximum3.0 milsRecommended film build per wet coat2.0 - 2.5 milsRecommended dried film build per coat1.0 - 1.5 mils

RTS Combinations: Volume Ratio:	EC750 : ECH70xx 4 : 1	EC750 : ECH70xx : D87xx 4 : 1 : 0.5	EC750 : ECH70xx : SLV814 4 : 1 : 10%
Applicable Use Category	Clear Coating	Clear Coating	Clear Coating (flexed)
VOC Actual (g/L)	155	146	145
VOC Actual (lbs/gal)	1.29	1.22	1.21
VOC Regulatory	250	249	243
(less water less exempt) (g/l)	230	249	243
VOC Regulatory	2.09	2.08	2.03
(less water less exempt) (lbs/gal)	2.09	2.00	2.03
Density (g/L)	1164	1171	1168
Density (lbs/gal)	9.71	9.77	9.75
Volatiles wt. %	57.1	59.5	58.7
Water wt. %	0.0	0.0	0.0
Exempt wt. %	43.7	47.0	46.2
Water vol. %	0.0	0.0	0.0
Exempt vol. %	37.9	41.3	40.3
Solids vol. %	44.4	42.0	43.2
Sq Ft. Coverage / U.S.gal. 1 mil. @ 100% transfer efficiency	712	674	693



Health and Safety

See Material Safety Data Sheet and Labels for additional safety information and handling instructions.

The contents of this package may have to be blended with other components before the product can be used.
 Before opening the packages, be sure you understand the warning messages on the labels and MSDS's of all the components, since the mixture will have the hazards of all its parts.



- Improper handling and use, for example, poor spray technique, inadequate engineering controls and/or lack of proper Personal Protective Equipment (PPE), may result in hazardous conditions or injury.
- Follow spray equipment manufacturer's instructions to prevent personal injury or fire.



- Provide adequate ventilation for health and fire hazard control.
- Follow company policy, product MSDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on MSDS.
- Always observe all applicable precautions and follow good safety and hygiene practices.

Emergency Medical or Spill Control Information (412) 434-4515; In Canada (514) 645-1320

Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the general public. Products mentioned may be hazardous and should only be used according to directions, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.



PPG Automotive Refinish

Bringing innovation to the surface.™

PPG Industries 19699 Progress Drive Strongsville, OH 44149 1-800-647-6050

PPG Canada Inc. 2301 Royal Windsor Drive Unit #6 Mississauga, Ontario L5J 1K5 1-888-310-4762