



PDS N1.4

April 2017

NEXA AUTOCOLOR® P850-1402 Spirit Wipe Slow Flash

PRODUCT DESCRIPTION

P850-1402 Spirit Wipe Slow Flash is a solvent-borne cleaner for use in removing contaminants on the surface prior to tack ragging and painting.

Note: The most important part of any repair process is a clean surface.



- *Fast Quality Repairs = Customer satisfaction*

Products	
P850-1402	Spirit Wipe Slow Flash

THESE PRODUCTS ARE FOR PROFESSIONAL USE ONLY

Spirit Wipe

PROCESS

MIX RATIO 	P850-1402 Spirit Wipe Slow Flash is sold Ready for Use
APPLICATION 	<ol style="list-style-type: none"> 1. Apply Spirit Wipe to panel with a clean rag. 2. Follow immediately with another clean rag to wipe off contaminants. <p>Note: For higher temperatures, fast air movement and large areas P8850-1402 Spirit Wipe - Slow Flash should be use.</p> <p>Caution: Do not use on fiberglass or plastic parts. Application on these surfaces can generate static build-up which can result in a flash fire.</p>

Performance Specifications

RTS Combinations:	P850-1402
Volume Ratio	As is
Applicable Use Category	Substrate Cleaner (Metal)
VOC Content (g/L)	738
VOC Content (lbs./gal)	6.16

HEALTH AND SAFETY

See Safety Data Sheet and Labels for additional safety information and handling instructions.

- The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and SDSs of all the components since the mixture will have the hazards of all of its parts.
- Improper handling and use, for example, poor spray technique, inadequate engineering controls and/or lack of proper Personal Protective Equipment (PPE), may result in hazardous conditions or injury.
- Follow spray equipment manufacturer's instructions to prevent personal injury or fire.
- Provide adequate ventilation for health and fire hazard control.
- Follow company policy, product SDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on SDS.
- Always observe all applicable precautions and follow good safety and hygiene practices.

EMERGENCY MEDICAL OR SPILL CONTROL INFORMATION (412) 434-4515; IN CANADA (514) 645-1320

Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the public. Products mentioned may be hazardous and should only be used according to direction, while observing precautions and warning statement listed on label. Statement and methods described are based upon the best information and practices known to PPG Industries. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results or fitness for any intended use, nor does PPG Industries warrant freedom from patent infringement in the use of any formula or process set forth herein.

For further information please contact:



Nexa Autocolor - USA
19699 Progress Drive
Strongsville, OH 44149

Nexa Autocolor - Canada
2301 Royal Windsor Drive Unit #6
Mississauga, Ontario L5J 1K5