

# **Product Data Sheet**

February 2018

INTERNATIONAL MASTER
FOR PROFESSIONAL USE ONLY



W0617V\_TV

# EHS Turbo Plus Clearcoat P190-1280

Product	Description
P190-1280	EHS Turbo Plus Clearcoat
P210-7644	EHS Hardener - Standard
P852-6442	EHS Thinner - Slow
P852-6444	EHS Thinner - Medium
P852-6446	EHS Thinner - Fast

#### **Product Description**

P190-1280 is the new premium CT Clearcoat from Autocolor. Designed specifically to meet the toughest requirements of today's fleet market, P190-1280 delivers outstanding final appearance and durability over either solvent or waterborne Basecoats. Formulated to make life simple, P190-1280 offers easy application, fast baking and reliable polishing.

When used in accordance with the recommendations laid down in this data sheet, P190-1280 combined with *CT Waterborne and Solventborne Basecoats* will provide a Basecoat/Clearcoat finish with a VOC of less than 420g/l.







NEXA AUTOCOLOR®, AQUABASE® and TURBO PLUS® are registered trademarks of PPG Industries Ohio, Inc. Copyright in the above product numbers that are original is asserted by PPG Industries.

Scotchbrite® is a trademark of 3M UK Plc. .

Innovating Repair Solutions

Process		
	HVLP	
	P190-1280 Clear 3 parts P210-7644 Hardener 1 part P852-644x Thinner 0.5 part	
	NOTES:  1. Stir paint well before mixing and use stick to ensure correct ratio of paint hardener and thinner  2. Stir paint IMMEDIATELY after activation	
	Pot Life at 20°C: 2 hours  The activated paint should be applied as soon as possible after activation  Clean gun immediately after use	
<b>∏s</b>	19-22 secs DIN4 @ 20°C (24-28 secs BSB4) @ 20°C  For optimum spray application properties ensure paint temperature is 20-25°C	
HVLP	Gravity / Suction: Fluid tip: 1.4-1.8 mm Pressure Feed: 1.0 – 1.2 mm  Pressure: As per spraygun manufacturers recommendations  2 single coats	
(†(†( :::::::::::::::::::::::::::::::::	Minimum of 10 minutes between coats at 20°C  No flash-off required before stoving	
	Air dry at 20°C  Dust Free 45 minutes Handleable - 4 hours Into-Service - 16 hours  Stoving at metal temperature of: 50°C 60 minutes 60°C 30 minutes 70°C 20 minutes Into-Service When cool	
RECOAT	After "Into-Service" times	



## **General Process Notes**

#### **SUBSTRATES**

CT P961-lineAQUABASE® Plus Waterborne Basecoat activated with 30% by volume of P935-3006 activator, please refer to V1450V TDS.

CT P422 and P482 lines Solventborne Basecoats activated with 10% by volume of P210-982 hardener, please refer to V4130 TDS.

TURBO VISION Premium High Flow Topcoat Multistripe Process, please refer to Y0104 TDS.

#### **PREPARATION**

The substrate to be painted must be dry, clean and free from grease.

Basecoat areas which have been left overnight should be thoroughly Tak ragged before application of P190-1280.

#### **PAINT TEMPERATURE**

As with other paint systems, optimum spray application is achieved if the paint is allowed to reach room temperature (20-25°C) before use. This is particularly important for high solids systems. It is strongly recommended that cold paint is warmed to a minimum of 15°C before application. Below this temperature paint application performance may be adversely affected.

In order to remain VOC compliant do not add extra thinner to adjust the spraying viscosity.

#### **HVLP APPLICATION**

The most suitable HVLP gun for the application of Commercial Transport products is the pressure feed system.

Air cap pressure: 0.675 bar (10psi) maximum Paint pressure: 0.3-1.0 bar (5-15 psi)

If long fluid lines are used, the paint pressure will need to be increased.

#### **RECOAT**

P190-1280 can be recoated with itself or any other **Nexa Autocolor** primer, undercoat or topcoat after the Into-Service times stated.

#### **OTHER INFORMATION**

Allow finishes to harden thoroughly before subjecting to vehicle washes. This can take a number of weeks if vehicles are air-dried in cold conditions and/or paint film thicknesses are excessively high.

#### **DEMASKING**

Care must be taken when demasking areas which have been coated with P190-1280 EHS Turbo Plus Clearcoat.

Low bake – It is recommended to demask whilst the vehicle is still warm from the oven. Demasking once the vehicle is cold may result in clearcoat delamination under certain conditions.

Air-dry: De-mask either before 6 hours drying time or after 36 hours drying time. Demasking at times between 6 and 36 hours may result in clearcoat delamination under certain conditions.



### **VOC INFORMATION**

The EU limit value for this product (product category: IIB.d) in ready to use form is max. 420g/litre of VOC. The VOC content of this product in ready to use form is max. 420g/litre when mixed with P852-1792 EHS Turbo Plus Additive Thinner - Medium

Depending on the chosen mode of use, the actual ready to use VOC of this product may be lower than that specified by the EU Directive code.

These products are for professional use only, and are not to be used for purposes other than those specified. The information on this TDS is based on present scientific and technical knowledge, and it is the responsibility of the user to take all necessary steps in order to ensure the suitability of the product for the intended purpose.

For Heath and Safety information please refer to the material Safety Data Sheet, also available at: http://www.ppg.com/Autocolor MSDS

### For further information please contact:

Customer Service Sales Group PPG Industries (UK) Ltd Needham Road Stowmarket Suffolk IP14 2AD

Tel: 01449 771771 Fax: 01449 773472



**NEXA AUTOCOLOR®, AQUABASE®** and **TURBO PLUS®** are registered trademarks of PPG Industries Ohio, Inc. Copyright in the above product numbers that are original is asserted by PPG Industries. Scotchbrite® is a trademark of 3M UK Plc.